



Firstly, thank you for purchasing our delete kit!

When fitting this kit, please ensure you are doing so in dry conditions. Do **not** attempt to fit this kit if it is pouring with rain, as tempting as it may be!

This is a DIY kit and to ensure great results, you should follow our steps closely.

Items that will help whilst installing this kit:

Microfiber cloth.
Clear tape.
Glass cleaner.

PREPERATION

- 1)** Once the rear wiper motor / wiper arm is removed, you need to prepare the glass.

Clean the front and back of the window with glass cleaner or soap and water.

Ensure all contamination is removed from the glass.

Dry the glass with a clean microfiber cloth or similar.

INSTALLATION

- 2)** Before you remove the protective film, test fit the delete plug to ensure you know how to get it through the hole. Some vehicles are limited for space, so ensure you do this.

Push the delete plug in to the wiper hole from the back of the window (from inside the hatch) ensuring you are square to the glass.

Do **NOT** try to fit this kit from the outside as it will not be flush and this is the wrong way. Treat this as a practice run as the next step can get a little messy!



INSIDE HATCH



OUTSIDE WINDOW

- 3)** Ensure you do not remove the protective film just yet!
- 4)** Add the supplied sealant to the edge of the delete plug by attaching the green application needle to the syringe of window bond.
- 5)** Press the delete plug through the wiper hole from the **BACK** of the window.
- 6)** Apply pressure to the delete plug until you get perfect fitment.
Once in place and you are happy with the fitment of the delete plug, apply clear tape to the back of the plug to hold in position (as you would whilst bonding side skirts etc.) to ensure it sets in the perfect position.
This tape can be removed after 1 hour as the sealant should now be solid, but please take care when removing.
- 7)** You need to seal the outer side of the delete plug to ensure it is 100% waterproof.
Whilst doing this next step, ensure you apply pressure from the back of the delete to ensure you do not push it back through to window.
Smear sealant around the edges of the plug in to the small gap surrounding it and ensure that all gaps are filled.
Instantly wipe down the glass / delete plug ensuring they are fully clean and free from sealant before you leave to set.
- 8)** You can use the bag the kit came in to put over the wiper motor plug and cable tie in place so that no water can damage the plug.
- 9)** You can now remove the protective film to reveal the finished product.
- 10)** Put all trim back on to the boot hatch and the job is done!
- 11)** Leave the kit to set for atleast 72 hours before using any sort of pressure washer to wash the car.

**DO NOT TAMPER / POKE THE DELETE PLUG WHILST IT SETS.
DOING SO WILL RUIN THE INSTALLATION.
LEAVE THE SEALANT TO DO ITS JOB.**



@KILL_ALL_WIPERS



SEARCH : KILL ALL WIPERS



/KILLALLWIPERS



ORDERS@KILLALLWIPERS.COM

WWW.KILLALLWIPERS.COM